

TZ® Maintenance Instructions

Quartz Carpet is a low maintenance flooring system that will retain its natural beauty and structural integrity if it is looked after and maintained using this guide.

General Maintenance



Spilages are best cleaned immediately by dabbing with a sponge and then washing with warm water and a neutral cleaning detergent.

Dust and dirt can easily be removed with a vacuum cleaner.



Mops or micro-mops are recommended on a closed pore system, or to freshen up an open-pore floor.

Deep Cleaning - Interior



Using warm water with a neutral cleaning detergent, sweep clean in a circular motion with a soft broom.



Remove dirty water with wet extraction cleaner. Wet-rinse with fresh water and wet vacuum again.

Mechanical Damage

Should the floor become damaged through mechanical means, the Quartz Carpet applicator should be contacted immediately to quote for repairs.

Deep Cleaning - Exterior



Using warm water with a neutral cleaning detergent, sweep clean in a circular motion with a soft broom.



Rinse off loose dirt using an ordinary garden hose pipe with extended nozzle.



Remove dirty water with wet extraction cleaner. Wet-rinse with fresh water and wet vacuum again.

Extra Care Tips - For best results, ensure the dirty water is changed regularly.



Do NOT scrub with a stiff bristle brush.



Do NOT blast with a high pressure water hose.



Do NOT apply any neat chemicals like hydrochloric acid, or undiluted chlorine.

